Ice Machine Parts List for Series RFS-0650 Models

RFS0650 EVAPORATOR COMPARTMENT



	DESCRIPTION	PART NO.
1	Compressor	
	a. 220/60/1	000008970
	b. 115/60/1	000008549
2	Condenser Fan Motor	
	a. 220/60/1	000005579
	b. 115/60/1	000008302
3	Air Cooled Condenser	000005631
4	Water Cooled Condenser	000008299
5	Water Reservoir Only	000005747
6	Compressor Contactor	
	a. 220/60/1	000008462
	b. 115/60/1	000008558
7	Low Pressure Switch (LPCO)	000006076
8	Bin Thermostat	000005765
9	Fan Cycle Control	
	a. 220/60/1	000006060
	b. 230/50/1	000006191
10	ON /OFF Rocker Switch	000005763
11	Electronic Noise Reducer (Radio Interference Filter) 220/60/1	
	a. Common	000005678
	b. Air-Cooled Only	000005680
12	Float Microswitch	000005760
13	Water Inlet Valve	
	a. 220/60/1	000006058
	b. 115/60/1	000006063
14	Water Regulating Valve	000008296
15	Water-Cooled Only Drain Manifold	000008300
16	Evaporator Drain Tap	000008552
17	Liquid Line Drier	000005676
18	Ice Chute	000005730
19	Ice Chute Safety Switch	000005762
20	High Pressure Switch	000008557
21	Rotation Sensor	000005755
22	Expansion Valve	000008548
Miscellaneous – Brackets, Screws, Etc.		
23	Condenser Fan Blade	
	a. 220/60/1	000005689
	b. 115/60/1	000006190
24	Drain Manifold 220/60/1 or 230/50/1	000006161
25	Access Valve	
	a. Fitting	000006408
	b. Core	000006409
	c. Cap	000006410
26	Screws	
	a. M5 x 10TC	000009040
	b. 3.9 x 13TC	000009041
27	Backflow Preventer	
	a. 60 Hz - 3/8”	000009971
	b. 50 Hz - 3/4”	000009972

RFS-0650 EVAPORATOR ASSEMBLY



	DESCRIPTION	PART NO.
1	Evaporator Assembly	000005683
2	Foundation	000005694
3	Gear Motor Assembly	
	a. 220/60/1	000008947
	b. 115/60/1	000005698
4	Gear Motor Capacitor (not shown)	
	a. 115/60/1	000007825
	b. 230/50/1	000007822
	c. 220/60/1	000007823
5	Insulating Cap	000005733
6	Bearing Cap	000005645
7	Snap Ring	000005758
8	Auger Bolt	000005600
9	Bearing Shim	000005610
10	Self Lubricating Disc	000005651
11	Upper Bearing	000005606
12	Upper O-ring	000005736
13	Cutter Head	000005648
14	Auger	000005596
15	Water Seal	000005778
16	Evaporator	000005683
17	Lower O-ring	000005584
18	Water Seal Retainer	000005781
19	Lower Bearing	000005603
20	Flex Jaw Coupling Lower	000005643
21	Flex Jaw Coupling Spider	000005644
22	Flex Jaw Coupling Upper	000005572
23	Ice Chute Kit	000007915
	a. Ice Exhaust with Microswitch	000007906
	b. Locking Strip	000007907
	c. Bulb Holder	000006540
	d. Ice Outlet Pipe Assembly	000007913
	e. Cross Bar	000007914
24	Ice Chute Extension	000008642

RFS-0650 PANELS



	DESCRIPTION	PART NO.
1	Top Panel	000008759
2	Back Panel	
	a. 115-220/60/1	
	Air	000009103
	Water	000009104
	b. 230/50/1	
	Air	000008836
	Water	000008971
3	Left Side Panel	000008768
4	Right Side Panel	000008757
5	Front Panel Assembly	000008755
6	Air Filter	000008837

† Refer to Cross Reference Guide